

NXB-63、NXB-63H Miniature Circuit Breaker

User Instruction

♠ Safety Warning

	produ essional		can	only	be	installed	and	d maintained	by
2 Insta	llation	in	anv	damp.	con	densed-ph	iase	environment	with

 When the product is being installed or maintained, the power must be switched off.

inflammable and explosive gas is forbidden.

- 4 You are prohibited from touching the conductive part when the product is operating.
- S It is prohibited to let children play with the product or the package.
- (§) Tighten the wiring screws when installing the product to prevent wires from loose or being pulled out. Select wires strictly according to instructions and connect them to proper power supply and load.
- [7] The product cannot protect people from electric shock or against power imbalances.
- 8 Do not install the product at places where gas media can cause metal corrosion and insulation damage.
- 9 The product is not suitable for the direct starting of high-inductive and high-capacity loads, such as fans, electric motors, electric heating equipment, capacitor cabinets, etc.

1 Purpose of Use

NXB-63 and NXB-63H series miniature circuit breakers are mainly used for the circuit of AC 50Hz or 60Hz with rated voltage of 240V or 415V and rated current of 63A, which provide overload and short-circuit protection and are also used as the infrequent making/breaking operation of the circuit under normal conditions.


Key Technical Parameters

Table 1 Key Technical Parameters


3 Installation

1. Outline and installation dimensions

Unit:mm



2. On-off indication




3. Installation






4. Disassembly



5. Wiring: copper wires only

Table 2 Copper wire cross-sectional area

Rated current In (A)	Copper wire cross-sectional area S (mm²)		
1~6	1		
10	1.5		
16、20	2.5		
25	4		
32	6		
40、50	10		
63	16		



4 Maintenance

- 1. Check the circuit breaker on a regular basis during operation;
- 2. After the circuit breaker cuts off the overload or short-circuit current, the fault should be eliminated before closing the circuit breaker.

Table 3 Analysis and troubleshooting of common faults

Symptoms	Cause analysis	Troubleshooting method	
	Short circuit at load end	Eliminate the fault	
The handle cannot	Fault occurs to the operating machanism.	Replace the product	
breaker	The rated current of the circuit breaker does not match the load current	Replace with product of proper specifications	
Temperature is	The wire is loose or not properly fixed by wiring screws.	Tighten the wiring screws	
too high	The cross-sectional area of the selected wire is too small	Replace with wire of proper specifications	
	The wire strip length is too short.	Re-strip the wire	
No power	The wire is loose or not properly fixed by wiring screws.	Tighten the wiring screws	

5 Environmental Protection

In order to protect the environment, the product or product parts should be disposed of according to the industrial waste treatment process, or be sent to the recycling station for assortment, dismantling and recycling according to local regulations.

CHNT

QC PASS

NXB-63、NXB-63H Miniature Circuit Breaker IEC/EN 60898-1

Check 12

Test date: Please see The packing

ZHEJIANG CHINT ELECTRICS CO.,LTD.



NXB-63、NXB-63H Miniature Circuit Breaker User Instruction

Zhejiang Chint Electrics Co., Ltd.

Add: No.1, CHINT Road, CHINT Industrial Zone,North Baixiang, Yueqing, Zhejiang 325603,P.R.China E-mail: global-sales@chint.com

Website: http://en.chint.com





